

FITTING AND POSITIONING OF LEGS AND PANEL CLIPS FOR HIGH LEVEL VERSION

- 1) LOCATE THE LEG SOCKETS TO THE SQUARE AREAS OF THE TRAY (THERE WILL BE A MINIMUM OF 5 DEPENDING ON THE SIZE OF TRAY SUPPLIED) (PLEASE SEE FIG 1 BELOW)
- 2) LEVEL THE LEGS TO ALLOW FOR THE HEIGHT OF THE PANEL SUPPLIED
- 3) THE PANEL CLIPS SUPPLIED FIT TO THE RECTANGULAR SECTIONS LOCATED AROUND THE RIM OF THE TRAY IN THE LOCATIONS WHICH REQUIRE THEM TO FIT THE PANEL(S) (PLEASE SEE FIG 1 BELOW)
- 4) MARK ON WALL UNDER RIM OF TRAY. REMOVE TRAY AND FIT WOODEN BATTONS TO SUPPORT SIDE OF TRAY ON THE TOUCHING WALLS.
- 5) RELOCATE TRAY ADDING A LIBERAL AMOUNT OF SILICONE SEALANT TO EDGES OF THE TRAY TO BE ADHERED TO THE WALL. PUSH TRAY BACK INTO POSITION.
- 6) THE PANELS MAY REQUIRE TRIMMING TO THE WALL SURFACE TO GIVE A PERFECT FIT

