

This instruction needs to be used in conjunction with the instruction included in the bath.

1

Place the plinth on two wooden blocks. Apply silicone on the surface where the bath N15 sits on. Also apply silicone on the bottom of the bath.

2

Put bath N15 on the plinth and adjust the bath slightly to ensure it is in the proper position. Allow the silicone to dry.

3

Install the waste by following the instruction supplied with the bath and waste.

4

Make sure the four feet underneath the plinth level with the bottom of the plinth. The feet are for leveling only and not to bear the weight of the bath. Please adjust any of the feet as the above diagram if the floor is not perfect flat.

5

Securing your bath to the floor:
When the bath is in position and the installation is complete, it is recommended that you apply a bead of silicone around the bottom of the plinth to secure it to the floor.

Care and Maintenance

The product is made from polished stainless steel. Clean with water or a soft detergent and dry with a soft cloth. Do not use detergents containing hydrochloric acid or caustic chemicals, or abrasive materials, chemicals or cloths.