



SWIFT - Freestanding Bath Tub Installation & Aftercare Instructions

Retain for future reference



Customer Services

Soakology, Unit 5, Brassmill Lane Enterprise Centre Brassmill Lane, Bath, BA1 3JN
t. 0845 862 9888 e. contact@soakology.co.uk w: www.soakology.co.uk

Part of Total Bathroom Enterprises Ltd
VAT No.153612626 Company No. 8260845

SWIFT - Freestanding Bath Tub

Installation & Aftercare Instructions

IMPORTANT

Before commencing installation, read these instructions carefully. Installation must comply with any requirements imposed by local authorities. Ensure that there is no damage to the bath. Keep the protective film on the bath throughout the installation period.

Installation Procedures

1. Remove a small area of the protective film from around the waste and overflow holes as once the fittings are in place it may be difficult to remove. Before installation disconnect the overflow pipe from the waste housing to make installation easier.
2. Disassemble the overflow and connect the overflow pipework as shown in the diagram, ensuring the overflow washer is positioned on the outside surface of the bath and the overflow fixing bracket (A) is on the inside of bath tub. Tighten the fixing screw securing the bracket to the overflow body (B). Ensure that the seal between the overflow washer and bath tub is tight to prevent leakages.
3. Reattach the overflow cover (C) to the overflow fixing bracket. The water inlet gap should be at the bottom of the cover.
4. Separate the waste washer (D), waste drain (E), Pop-up mechanism (F) and waste cover (G) from the waste housing and washer (H).
5. With the waste washer and waste drain inside the bath tub, screw into the waste housing and washer positioned underneath the bath - forming a watertight seal. Ensure that the outlet on the waste housing is positioned so that the overflow pipe can be reattached without twisting or bending the pipe.
6. Attach the siphon (I) to the waste housing and connect to the bathroom's waste pipes. Water test the bath to check the bath is draining correctly and to check for any leaks. If draining correctly, remove the protective film from the bath and apply silicone sealant around the base of the bath before allowing to cure for 24 hours.

Aftercare

To preserve the polished surface of the bath, after use clean with a soft cloth with warm soapy water to wash away any body oils or soap. It is recommended that the bath is only cleaned with warm soapy water and that powders, pastes, cream cleaners, thinners, and window cleaning sprays are not used on the bath's surface.

Customer Services

Soakology, Unit 5, Brassmill Lane Enterprise Centre Brassmill Lane, Bath, BA1 3JN
t. 0845 862 9888 e. contact@soakology.co.uk w: www.soakology.co.uk

