

SAGE - Freestanding Bath Tub Installation & Aftercare Instructions

Retain for future reference



Customer Services

Soakology, Unit 5, Brassmill Lane Enterprise Centre Brassmill Lane, Bath, BA1 3JN
t. 0845 862 9888 e. contact@soakology.co.uk w: www.soakology.co.uk

Part of Total Bathroom Enterprises Ltd
VAT No.153612626 Company No. 8260845

SAGE - Freestanding Bath Tub

Installation & Aftercare Instructions

IMPORTANT



Before commencing installation, read these instructions carefully. Installation must comply with any requirements imposed by local authorities. Ensure that there is no damage to the bath. Cover the bath with a clean dust sheet throughout the installation period.

Installation Procedures

1. Carefully tilt the bath tub on its side and remove the nuts and washers from the base of the tub. Position the acrylic tray on the bottom of the tub and bolt the tray to the base of the bath. The adjustable feet on the tray can then be adjusted and fixed in place with the fixing nuts.
2. Tilt the bath over to allow access to the waste and overflow holes. Adjust the overflow pipe so that it is at a suitable height for the overflow hole, making sure the rubber seal covers where the overflow pipe joins the waste pipe.
3. Disassemble the overflow and connect the overflow pipework as shown in the diagram, ensuring the rubber washer is positioned on the outside surface of the bath. Screw the overflow cover (A) into the overflow housing (B) until tight.
4. Separate the waste drain (C), Pop-up mechanism (D) and waste cover (E) from the waste housing (F).
5. Using clear silicone sealant, apply sealant to the underside of the waste drain to form a watertight seal. Ensuring the rubber washer is on the underside of the bath tub, reconnect the waste drain into the waste housing. Remove any excess sealant from inside the bath tub.
7. Water test the bath to check it is draining correctly and to check for any leaks. Finally, remove the protective film from the bath.

Aftercare

To preserve the polished surface of the bath, after use clean with a soft cloth with warm soapy water to wash away any body oils or soap. It is recommended that the bath is only cleaned with warm soapy water and that powders, pastes, cream cleaners, thinners, and window cleaning sprays are not used on the bath's surface.



Customer Services

Soakology, Unit 5, Brassmill Lane Enterprise Centre Brassmill Lane, Bath, BA1 3JN
t. 0845 862 9888 e. contact@soakology.co.uk w: www.soakology.co.uk